

N-FEED-LCD



KARMIK AUTOMATYCZNY AQUA NOVA N-FEED

LCD Auto-Feeder


PL INSTRUKCJA OBSŁUGI

ENG USE MANUAL

Cechy:

- Dokładna kontrola elektroniczna
- Do 5 razy dziennie podawanie pokarmu, od 1-3 cykli (obrotów) podczas karmienia.
- Możliwość karmienia płatkami oraz pelletem.

Części zamienne:



INSTALACJA

1. Karmnik działa z bateriami typu AA. Naciśnij przycisk MANUAL i upewnij się czy pojemnik na pokarm działa właściwie.
2. Wyjmij pojemnik na pokarm, zamknij ujście pokarmu, otwórz pokrywę pojemnika, następnie zainstaluj tak jak było pierwotnie, nie dodawaj pokarmu, pokarm zostanie dodany gdy zapoznasz się z ustawieniami i ustawisz wymagane okresy karmień.
3. Ustawienia karminika

a) Ustawianie czasu (rysunek 1):

Naciśnij SETTING/USTAWIENIA, kiedy wyświetli się godzina naciśnij "+" lub "-" i ustaw prawidłową godzinę. Następnie naciśnij SETTING/USTAWIENIA gdy wyświetlą się MINUTY, dokończ ustawianie czasu za pomocą przycisków "+" i "-".
Pozwól ustawionej godzinie i minucie migać przez około minutę, po tym okresie czas będzie już prawidłowo ustawiony i zapisany.

PL

b) Czas karmienia i cykle (obrazek 2)

Po ustawieniu czasu lokalnego możesz przystąpić do ustawień karmień.

Naciśnij SETTING/USTAWIENIA cyfry wskazujące godzinę na wyświetlaczu zaczną migać, teraz możesz zacząć ustawiać czas pierwszego karmienia. Naciśnij "+" lub "-" aby ustawić godzinę pierwszego karmienia. Naciśnij ponownie SETTING/USTAWIENIA i gdy minuty zaczną migać, zakończ ustawienia czasu pierwszego karmienia używając przycisków "+" i "-".

Naciśnij "SETTING/USTAWIENIA" ponownie i gdy cyfry zaczną migać ustaw używając "+" i "-" ile cykli karmień chcesz uzyskać (1, 2 czy 3 cykle). Gdy w pierwszym polu pojawi się cyfra "1" oznacza to jeden cykl. 2 oznacza 2 cykle, 3 oznacza 3 cykle. W ten sposób o określonej godzinie możesz uzyskać nawet do 3 cykli karmień. 1 cykl czyli jeden obrót oznacza normalne karmienie, 3 cykle czyli 3 obroty oznaczają intensywne karmienie.

Pozwól cyfrą migać przez jedną minutę i po tym czasie ustawienia zostaną zapisane.

- 4) Ustawianie kolejnych czasów karmień jest adekwatne do ustawiania pierwszego karmienia. 5 kolumn znajdujących się pod godziną określa ilość cykli w danym karmieniu. Zwróć uwagę na 6 przykładów ustawień – rysunek obok. Możesz ustawić od 1-5 karmień dziennie oraz od 1-3 cykli w każdym karmieniu.
- 5) Napełnij pojemnik pokarmem. Ustaw karmnik na szybie zbiornika, w miejscu w którym chcesz karmić ryby. Karmnik nie może dotykać wody. Ustaw okresy karmień według swoich upodobań.

⚠ 6) UWAGA


Nie wkładaj urządzenia do wody, jeśli woda się dostanie do środka osusz jak najszybciej urządzenie.

Jeśli nie używasz karmnika przez długi okres wyjmij baterię ze środka.

Wymień baterię jeśli karmnik nie działa prawidłowo


Po wymianie baterii należy ponownie ustawić okresy karmień.

Nie wkładaj wilgotnego pokarmu, czyść okresowo pojemnik na pokarm.




Rysunek 1


Przykłady ustawień:




1. Oznacza, że czas lokalny to 10:33




2. Oznacza, że pierwsze karmienie jest o 8:30, z 3 cyklami (obrotami)




3. Oznacza, że drugie karmienie jest o 12:00 z 2 cyklami (obrotami)



4. Oznacza, że trzecie karmienie jest o 15:30, z 1 cyklem (obrotem)



5. Oznacza, że 4 karmienie jest o 19:00, z 3 cyklami (obrotami)



6. Oznacza, że 5 karmienie jest o 23:30 z 2 cyklami (obrotami)



www.aqua-nova.pl


EURONOVA POLSKA Sp. z o.o.
POLAND, 87-300 Brodnica, ul. Sikorskiego 60a
www.aqua-nova.pl

Petras Fisheries Pty Ltd
2158, NSW, Australia, 9 Bangor Road, Dural
+61-2-96522125, www.novaeuro.com

Features:


- Accurate electronic control and clear LCD display.
- 5 different setting time with 1 – 3 rounds feeding, to meet various needs.
- Suitable for food pellet and flake.

ENG



Operations:

1. Open the battery housing, fix 2 AA batteries well. Press the "MANUAL" button, to make sure the food container can function well.
2. Take down the food container, close the feeding outlet and open the bottom cover to fill with food. Then re-assembly it to feeder host.
3. Auto feeding function as below instructions:
 - 1) Standard time setting (see picture 1):
 - Press "SETTING" button, when the HOUR 2 digits twinkle, press "+" or "-" button to set local standard HOUR time.
 - Then press "SETTING" button, when the MINUTE 2 digits twinkle, press "+" or "-" button to set local standard MINUTE time.
 - Finally, let the digits twinkle for one minute, local standard time will set up.



2) Feeding time & feeding round setting (see picture 2, 3, 4)

After setting up the local standard time, you can start to set up feeding time and round.

- Please refer to Picture 2. Press "SETTING" button, when the bottom squares outline and HOUR 2 digits twinkle together, you can start to set the 1st feeding time and round. Press "+" or "-" button to set your 1st feeding HOUR time.
- Then, press "SETTING" button, when the bottom squares outline and MINUTE 2 digits twinkle together, press "+" or "-" button to set your 1st feeding MINUTE time.
- Press "SETTING" button again, when the bottom squares outline twinkles, press "+" or "-" to your preferred feeding round (1, 2 or 3 round). When "1" shows in 1st small square, means 1 round. When "2" shows in 1st small square, means 2 rounds. When "3" shows in 1st small square, means 3 rounds.
- Then, let the digits twinkle for one minute, the 1st feeding time and rounds will set up.

3) Please refer to below pictures.

The 2nd, 3rd, 4th and 5th feeding time and rounds are same operations as the 1st feeding. The 5 small squares shown feeding round(s) against 5 different feeding time.

Please refer to below 6 typical examples to elaborate setting operations.

- Means local standard time 10:33
- Means the 1st feeding is at 8:30 and 3 rounds.
- Means the 2nd feeding is at 12:00 and 2 rounds.
- Means the 3rd feeding is at 15:30 and 1 round.
- Means the 4th feeding is at 19:00 and 3 rounds.
- Means the 5th feeding is at 23:30 and 2 rounds.


If you do not need all 5 different feedings, you can set up your feeding among 1-5. Do not need to follow feeding sequence strictly.

- 4) Manual feeding: If you wish to enjoy feeding manually, please press the "MANUAL" button, the food container will run and feed accordingly.


4. Fix the LCD auto feeder to the edge of tank, adjust the feeding outlet width according to necessary, then the feeder can start to work.
5. Special reminder

Keep away from water. In case any water go inside, please handle immediately.


Take out the batteries if the LCD Auto-Feeder will be unused for long time. Please renew batteries when LCD Auto-Feeder can not run powerfully.




1. Means local standard time 10:33




2. Means the 1st feeding is at 8:30 and 3 cyles.




3. Means the 2nd feeding is at 12:00 and 2 cyles.



4. Means the 3rd feeding is at 15:30 and 1 cyle.



5. Means the 4th feeding is at 19:00 and 3 cyles.



6. Means the 5th feeding is at 23:30 and 2 cyles.

GWARANCJA / WARRANTY CONDITIONS

N-FEED-LCD

nazwa urządzenia / name of product

pieczęć punktu sprzedaży / stamp of the place of purchasing

PL

Urządzenie N-FEED-LCD objęte jest 24 miesięcznym okresem gwarancyjnym na bezawaryjność licząc od daty zakupu. Zachowaj dowód sprzedaży. Gwarancja obejmuje uszkodzenia powstałe z winy producenta, tzn. błędy w montażu czy wady materiałowe. Gwarancja nie obejmuje niewłaściwego użytkowania urządzenia N-FEED-LCD (nie przestrzeganie zasad właściwego użytkowania i konserwacji). Klient zgłaszający reklamację zobowiązany jest wysłać urządzenie wraz z dowodem zakupu na adres producenta lub dystrybutora.

ENG

The manufacturer provides a 24 month guarantee, beginning on the date of purchase. The guarantee covers defects arising from manufacturer fault i.e. defective materials or workmanship. It does not cover mechanical and other damage caused by improper handling or construction changes introduced by the user. If a claim is to be made, please return to the shop, where you have bought this product, and present receipt showing date of purchase, proof of date and purchase is a prerequisite for accepting the claim.

Demontaż / Disassembly

PL

Zgodnie z ustawą o zużytych sprzęcie elektrycznym i elektronicznym N-FEED-LCD nie należy wyrzucać do śmietnika. Selekcjonowanie i utylizacja tego typu urządzeń przyczyni się do ochrony środowiska naturalnego. Uwaga! Wyrzucanie sprzętu elektrycznego lub elektronicznego do śmietnika grozi karą grzywny. Użytkownik jest zobowiązany do dostarczenia zużytego sprzętu elektrycznego do wyspecjalizowanego punktu zbiórki, gdzie odpad zostanie przyjęty bezpłatnie.

ENG

It is forbidden to dispose of used electric and electrical equipment in a trash bin. Segregating and proper utilization of this kind of waste leads to conserving the resources of natural environment and allows avoiding negative influence on health as it can be endangered by improper waste handling. The user is responsible for delivering the used product to a specialized collection point where it will be accepted free of charge. You can obtain information about such a facility at the local authorities, or by asking either the seller or the manufacturer service.

